

Aztec Track Master™ Kato SD40/45

Track Master™ FRAME TM3105 S

Tools needed to do the job:

Small Phillips screwdriver / Soldering iron / Ruler/
Wire strippers / Safety glasses

Remove brushes, springs and caps from motor.

Pry brush holders from motor.

Remove power contact strips and set aside.

Solder wire to brush caps then to decoder board.

Soldering must be as small as possible to prevent shorting to frame.

Push brush holders in motor, replace brushes, springs and brush caps.

Put locomotive back together and test using the MRC instructions that came with your decoder.



2701 Conestoga Drive, Unit 113
Carson City, NV 89701

Tel: (775) 883-3327

Fax: (775) 883-3357

E-mail: aztecmfg@usa.net

Website: www.aztctrains.com

